




# Case Study Akron Spillway Dam

Akron, Ohio

#### **Akron Spillway Dam: General Characteristics**



#### **Akron Dam: Structural Monitoring System Overview**

Aim	To monitor the integrity and behavior of the spillway for possible failure or other possible damage and to integrate the sensing system into an already established optical network.	
Location	Akron, Ohio USA	
System Integrator	Chandler Monitoring Systems	
End Customer	City of Akron Water Supply	
Date	November 2012 to ongoing	
Instrumentation	(1) Luna sm130, Optical Sensing Interrogator	
Sensors	<ul> <li>(26) Luna os3610 long gage strain sensors</li> <li>(3) Luna os4350 temperature sensors</li> <li>(6) Luna optical accelerometers</li> <li>(2) FBG Tech tilt meters</li> </ul>	
Software	Luna ENLIGHT and IntelliOptics	
FBG Technology Benefit	Serial installation of FBG sensors allowed for quicker install compared to conventional electric strain gages. FBG sensors have reduced data drift and longer sensor lifetime compared to electric gages. The pre-existing optical network allowed for integration of FBG sensors with security cameras.	








### **Akron Spillway Dam: System Configuration**

The monitoring system instrumentation is composed of:


- Single optical interrogator (model sm130-700 dynamic interrogator)
- Long-gage strain sensors to better measure strain over the large area between buttresses
- Accelerometers, temperature sensors, and tilt meters for other crucial measurements



### **Akron Spillway Dam: Sensor Layout**


The optical monitoring system is composed of:


- Sensors put into two zones and split among the 4 channels
- 8 sensors installed in series in each channel







## **Akron Spillway Dam: Sensor Layout**








Channel 4






#### **Akron Spillway Dam: Sensor Configuration**

- The os3610s are mounted in pairs along the x and y axis on the centerline between buttresses as the walls between the buttresses are the mostly likely points of failure.
- The optical accelerometers are mounted on the face of the buttresses above the high water line to monitor for seismic activity and the effects of the nearby train.
- Temperature sensors, os4350, are mounted in each zone to monitor air temperature throughout the internal portion of the spillway.



1m os3610 strain gages



3-D accelerometer

#### **Akron Dam: Installation**



- Sensors were run from the control room along the length of the spillway.
- The os3610s were installed by grouting them directly into the concrete walls of the dam.








## **Chandler Monitoring Systems (CMS)**

Services	-CMS
Installation	CMS installation staff provides end-to-end installation of the SHM (structural health monitoring) systems. The CMS installation staff is insured, certified in safety procedures and trained and experienced in the latest technologies.
Monitoring	CMS provides complete monitoring services including analysis of data and regular customer reports. Included in the monitoring system are defined thresholds for alarms and alerts. CMS provides the customer with complete training on the system description, operation, and maintenance.
Software	CMS provided the customer with the IntelliOptics™ Software package. This is a customized graphical user interface software application package which provides the customer with a single monitoring interface for all of the system components. The IntelliOptics™ system monitors, gathers data, and provide alerts and analysis when various sensing systems approach or exceed established limits.









#### **Akron Spillway Dam: Software**

- The IntelliOptics software system gives a total overview of the system and the outputs for each sensor.
- It allows for the user to make notes, check the layout of the sensors, view the cameras set up for security, and much more.
- A key benefit to the system is that it can also be checked remotely and send alerts if something fails.





#### **Akron Spillway Dam: Future Plans**



- There are three planned stages for installation of the fiber optic system.
- Stage one is complete and data collection has begun to help determine necessary monitoring for later stages.



#### **Akron Spillway Dam: Acknowledgements**

- This work received federal funding and was organized by the City of Akron Water Supply.
- The Authors Wish To Thank:
  - Jeff VanNatten: City of Akron Water Supply (Water Plant Technician)
  - George Reed: City of Akron Water Supply (Plant Maintenance Supervisor)
  - Jeff Bronowski: City of Akron Water Supply (Water Supply Manager)
  - Bob Geiser, P.E.: City of Akron Water Supply (Water Plant PE)
  - Donald Shaw, P.E.: Engineering and Management Consultant; CMS
  - Keith Chandler, President/CEO: CMS
  - Jennifer Chandler, VP of Operations: CMS
  - Justin Chandler, Field Installations Supervisor: CMS

Luna Innovations

Tel: 404-325-0005

www.lunainc.com

